


WIRE WHEELS

Dense filled cup brushes with threaded arbor holes for use on electric or "Air Style" right angle grinders. Flexible drives and stationary set-ups. For general duty brushing of concrete, rust, paint, etc. Comes standard with $\frac{5}{8}$ "-11 nut arbor.


No.	Size	Description	Wt (lbs)
Cups			
TAB WW4	4"	Double Row Wire Knot	2.00
TAB WW5	5"	Double Row Wire Knot	2.40
TAB WW6	6"	Double Row Wire Knot	2.40



KNOT WIRE WHEEL BRUSHES

Carbon Steel. A first run brush for cleaning welding beads. The knotted tufts offer little flexibility and cover more surface. Used for surface cleaning, rust, welds, deburring.

No.	Size	Description	Wt (lbs)
Wire Wheel			
TAB WK4	4" x $\frac{3}{8}$ " x $\frac{5}{8}$ "-11	Single Wire Knot Wheel	1.40



ADAPTORS

SNAP HANDLE

1 $\frac{1}{4}$ " push button snap adaptors allow you to use lightweight 1 $\frac{1}{4}$ " push button snap handles with threaded extension bracket assemblies.

No.	Description	Wt (lbs)
TTA SML	MALE	1.20
TTA SFL	FEMALE	1.00

1 $\frac{3}{8}$ " push button snap adaptors will adapt any screw extension bracket like magnesium bull floats to a 1 $\frac{3}{8}$ " push button snap handle.

No.	Description	Wt (lbs)
TTA SM	MALE	1.00
TTA SF	FEMALE	1.50

Starter adapts 1 $\frac{1}{4}$ " push button snap handles to 1 $\frac{3}{8}$ " push button snap ends.

No.	Wt (lbs)
TTA S	0.50

EXTENSION BROOM

Attach paint rollers, brooms, etc. to molded thread extension handles.

No.	Wt (lbs)
TTA T	0.10

